



Castle Bouncer Operating Instructions

1. Children must remove all footwear and jewelry. No gum or face paint allowed.
2. Age limit 12 years and under.
3. Instruct each child the following Safety Rules:
 - * No bare feet allowed
 - * No somersaults or back flips
 - * No climbing the walls or running into them aggressively
 - * No jumping or sitting on the step outside the Bouncer
 - * No pushing or bumping into others
4. Children waiting should stand 3 feet in front of the bouncer to give those exiting room. Parents and other spectators should be kept back a safe distance from the ride.
5. Do not have more than 4 - 6 Children on the Bouncer at one time.
6. Supervisor *MUST NOT* leave the unit unattended during the ride for any reason.
7. Wait until all have exited before a new group enters. The operator should assist the users while they exit the ride.
8. Group children by age - separate children from smaller ones.