

Heat Cannon



START UP INSTRUCTIONS:

1. Connect the POL inlet on the regulator of the heater to the propane cylinder.
2. Open the cylinder valve.
3. Leak test the cylinder connection.
4. Depress the fan switch to the "ON" position. The fan motor will start and air will be pushed through the outlet of the heater.
5. Depress the heat switch to the "ON" position. The burner should ignite and hot air will be pushed through the outlet of the heater.
6. Set the Thermostat (if provided) to desired temperature.

TO SHUT DOWN:

1. Close the cylinder valve on the propane cylinder.
2. Move both the "FAN" and "BURNER" switches to the "OFF" position.
3. Disconnect heater from the cylinder.