



# Popcorn Machines

## Tips

**Light and Warmer Switch** - turns on heat lamp and strip heater under corn pan.

**Kettle Heat and Stir Shaft** - turns on motor that drives kettle agitator and heat element inside kettle

## To Pop

1. Turn on Kettle heat switch and Light switch.
2. Let machine warm up for about 10 minutes.
3. "Test pop" a kettle of corn: place oil measure in kettle with three corn kernels; when kernels pop, place remainder of oil, measured corn and flavouring in kettle; close lid.
4. When corn has popped, rotate the handle to empty popcorn from kettle; return kettle to upright position.
5. Repeat the cycle; subsequent batches are always more flavourful than the initial batch.
6. Turn off kettle heat and kettle motor.
7. Wipe exterior of kettle with heavy cloth after cooling of kettle to prevent burn or stain of oil drippings.